



# DOPSTATION™

## Thermostatically-Controlled Dop Pot Users Guide

The Inland DopStation™ uses a thermostatically-controlled ceramic heater for melting wax and keeping it at the perfect temperature. It carries our One Year Full Confidence Warranty.

### Safety

- The DopStation and wax get very hot and will burn your fingers if you are not careful. Use with caution and keep a small container filled with cool water handy to wet your fingers.
- Set the unit on a sturdy, level work surface that is heat tolerant.
- Keep out of the reach of children
- Use only in a properly grounded outlet. The polarized plug will only fit one way – do not force the large polarized blade into a smaller ungrounded outlet.
- Unplug the unit when not in use. Use the lighted rocker switch for convenience when working.

Supplied by Reental International  
t/a Inland Lapidary (USA)

Local agent: Aussie Sapphire  
[www.AussieSapphire.com.au](http://www.AussieSapphire.com.au)

## Using the DopStation

- Plug in the DopStation.
- Place up to a full ¼ lb. stick of dop wax into the pan. Break the stick into pieces so they don't melt outside of the pan.
- Turn on with the rocker switch and allow the wax to melt fully. The wax will melt to proper consistency in about 20 minutes and maintain consistency as long as the DopStation is turned on.
- Turn off when done, leaving the unused wax in the pot to re-solidify. Unplug the unit if not being used for extended periods of time.
- Stones can be preheated by placing them on the wide, black rim around the pot. Be careful. The stones will get hot! Most stones will heat to dopping temperature in under a minute. Do not leave stones on the pot for longer periods. Some stones (like opals) are sensitive to heat and may crack. Others (like amber) may even begin to melt at the high temperatures of the DopStation. For heat-sensitive materials, only heat for short periods.



## Helpful Tips

- Store your dop sticks, with or without stones dopped to them, in the convenient holders at the rear of the DopStation.
- Find more detailed instructions on the dopping process and creating cabochons in our online "How to Make Lapidary Cabochons" at [www.inlandlapidary.com](http://www.inlandlapidary.com)

## Maintenance

Used carefully, your new Inland DopStation should be free of maintenance concerns. However, it's always a good idea to occasionally inspect any electrical cord or switch for wear, and replace as needed (don't try to repair a worn cord or switch).

## Accessories

- **Green Dop Wax:** ¼ lb. sticks for general purpose use. Inland no. 450100.

## Service

If you have any questions or comments regarding the use of this or any other Inland brand products, please email us at [helpdesk@inlandcraft.com](mailto:helpdesk@inlandcraft.com), or call Inland Customer Service at (800) 521-8428 9am to 5PM EST, or you can write us at:

**Inland Craft Products, Co.**  
32052 Edward Drive  
Madison Heights MI 48071  
[www.inlandlapidary.com](http://www.inlandlapidary.com)